

## Delivery Program

<b>Product Category:</b>	Load Cells
<b>Model:</b>	127
<b>Order Code(s):</b>	BL807

### USE THE CHART BELOW TO DETERMINE LEAD TIMES<sup>1</sup>

The range or option code with the longest lead time dictates the shipping time. Categories shaded in grey are required selections. For example (reference only):

If you build this:	The order configuration is this:	The delivery class is:
BL807 + 50 kg load range (LF), -20 °C to 55 °C, Unamplified, mV/V output (2u), and 5 m of flying leads electrical termination	BL807 – LF – 2u	Quick ship, ships in 1 to 5 days

	Quick-ship (Ships in 1-5 days)	Fast track manufacture (Ships within 4 weeks)	Build-to-order (Call Honeywell 1-800-848-6564 or +1 614-850-5000)
Load range	50kg (LF), 100kg (LH)		
Temperature compensation	-20 °C to 55 °C, [-4 °F to 131 °F] *		
Internal amplifiers	2u. Unamplified, mV/V output *		
Electrical termination	5 m of flying leads *		

<sup>1</sup> LEAD/SHIPPING TIMES ARE APPROXIMATIONS AND MAY VARY DEPENDING ON PRODUCT AVAILABILITY AND OTHER FACTORS. IN NO EVENT SHALL HONEYWELL BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY, OR PUNITIVE DAMAGES, EVEN WHERE HONEYWELL HAS BEEN ADVISED OF, OR IS OTHERWISE AWARE OF, THE POSSIBILITY OF SUCH DAMAGES, FOR FAILURE TO MEET SUCH LEAD / SHIPPING TIMES.

\* Default options.

Note: Before selecting option/s, please refer to the Test and Measurement catalog or product data sheet for special application notes and compatibility. A catalog can be ordered on-line at <https://home.honeywell-online.com/newTMcatalog>. Product data sheets are available on Honeywell's web site at <http://content.honeywell.com/sensing/sensotec/catpages.asp>.