

Delivery Program

| | |
|--------------------------|------------------------|
| Product Category: | Torque |
| Model: | 1115 Series |
| Order Code(s): | 1115A and 1115K Series |

USE THE CHART BELOW TO DETERMINE LEAD TIMES¹

The range or option code with the longest lead time dictates the shipping time. Categories shaded in grey are required selections. For example (reference only):

| If you build this: | The order configuration is this: | The delivery class is: |
|------------------------------------|----------------------------------|--|
| 1115 + 50 in-lbs torque range (50) | 1115A -50 | Build-to-order, call Honeywell for lead time |

Model 1115 Slip Ring Torque Sensor

| | Quick-ship (Ships in 1-5 days) | Fast track manufacture (Ships within 4 weeks) | Build-to-order (Call Honeywell 1-800-848-6564 or +1 614-850-5000) |
|---------------|-----------------------------------|--|---|
| Torque ranges | | | Model 1115A-50: 50 in-lb Model 1115A-100: 100 in-lb Model 1115A-200: 200 in-lb Model 1115A-500: 500 in-lb Model 1115A-1K: 1,000 in-lb Model 1115K-50: 50 in-lb Model 1115K-100: 100 in-lb Model 1115K-200: 200 in-lb Model 1115K-500: 500 in-lb Model 1115K-1K: 1,000 in-lb Model 1115K-2K: 2,000 in-lb Model 1115K-5K: 5,000 in-lb Model 1115K-10K: 10,000 in-lb |

¹ LEAD/SHIPPING TIMES ARE APPROXIMATIONS AND MAY VARY DEPENDING ON PRODUCT AVAILABILITY AND OTHER FACTORS. IN NO EVENT SHALL HONEYWELL BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY, OR PUNITIVE DAMAGES, EVEN WHERE HONEYWELL HAS BEEN ADVISED OF, OR IS OTHERWISE AWARE OF, THE POSSIBILITY OF SUCH DAMAGES, FOR FAILURE TO MEET SUCH LEAD / SHIPPING TIMES.

Options: for special options or metric versions, consult factory.

Accessories offered: mating connectors/cable assembly

Note: Before selecting option/s, please refer to the Test and Measurement catalog or product data sheet for special application notes and compatibility. A catalog can be ordered on-line at <https://home.honeywell-online.com/newTMcatalog>. Product data sheets are available on Honeywell's web site at <http://content.honeywell.com/sensing/sensotec/catpages.asp>.