

## Delivery Program

<b>Product Category:</b>	Torque
<b>Model:</b>	1228/1248
<b>Order Code(s):</b>	1228, 1248

### USE THE CHART BELOW TO DETERMINE LEAD TIMES<sup>1</sup>

The range or option code with the longest lead time dictates the shipping time. Categories shaded in grey are required selections. For example (reference only):

If you build this:	The order configuration is this:	The delivery class is:
1228 + 2,000 in-lbs torque range (2K)	1228 – 2K	Quick ship, ships in 1 to 5 days

Model 1228 and 1248 flange drive torque sensor  
 Model 1228 capacities from 2000 in-lb to 10000 in-lb  
 Model 1248 20,000 in-lb

	Quick-ship (Ships in 1-5 days)	Fast track manufacture (Ships within 4 weeks)	Build-to-order (Call Honeywell 1-800-848-6564 or +1 614-850-5000)
<b>Torque ranges</b>	Model 1228-2K: 2,000 in-lbs Model 1228-5K: 5,000 in-lbs Model 1228-10K: 10,000 in-lbs Model 1248-20K: 200000 in-lbs		

<sup>1</sup> LEAD/SHIPPING TIMES ARE APPROXIMATIONS AND MAY VARY DEPENDING ON PRODUCT AVAILABILITY AND OTHER FACTORS. IN NO EVENT SHALL HONEYWELL BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY, OR PUNITIVE DAMAGES, EVEN WHERE HONEYWELL HAS BEEN ADVISED OF, OR IS OTHERWISE AWARE OF, THE POSSIBILITY OF SUCH DAMAGES, FOR FAILURE TO MEET SUCH LEAD / SHIPPING TIMES.

**Options:** for special options or metric versions, consult factory.

**Accessories offered:** mating connector/cable assembly, speed sensor

*Note: Before selecting option/s, please refer to the Test and Measurement catalog or product data sheet for special application notes and compatibility. A catalog can be ordered on-line at <https://home.honeywell-online.com/newTMcatalog>. Product data sheets are available on Honeywell's web site at <http://content.honeywell.com/sensing/sensotec/catpages.asp>.*