

Delivery Program

Product Category:	Torque
Model:	1205B
Order Code(s):	WI1100

USE THE CHART BELOW TO DETERMINE LEAD TIMES¹

The range or option code with the longest lead time dictates the shipping time. Categories shaded in grey are required selections. For example (reference only):

If you build this:	The order configuration is this:	The delivery class is:
WI1100 + 212 °F compensated transmitter temperature (62s), remote display (62c), vibration/shock rated PSU (62j), 10.7 MHz RF operating frequency, 1 channel 4 mA to 20 mA isolated output (62e)	WI1100 – 62s – 62c – 62j – 62e	Build-to-order, call Honeywell for lead time

	Quick-ship (Ships in 1-5 days)	Fast track manufacture (Ships within 4 weeks)	Build-to-order (Call Honeywell 1-800-848-6564 or +1 614-850-5000)
RPM			Varies on application, consult Honeywell
Shaft diameter			Varies on application, consult Honeywell
Compensated transmitter temperature			62s. 100 °C [212 °F]
Display (receiver)			62c. Remote display
Vibration and shock (PSU)			62j. Vibration/shock rated PSU
RF operating frequency			10.7 MHz ¹
Analog output (receiver)			±10 Vdc @ 5 mA 62e. 1 channel 4 mA to 20 mA isolated output

¹ LEAD/SHIPPING TIMES ARE APPROXIMATIONS AND MAY VARY DEPENDING ON PRODUCT AVAILABILITY AND OTHER FACTORS. IN NO EVENT SHALL HONEYWELL BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY, OR PUNITIVE DAMAGES, EVEN WHERE HONEYWELL HAS BEEN ADVISED OF, OR IS OTHERWISE AWARE OF, THE POSSIBILITY OF SUCH DAMAGES, FOR FAILURE TO MEET SUCH LEAD / SHIPPING TIMES.

* Default options.

Note: Before selecting option/s, please refer to the Test and Measurement catalog or product data sheet for special application notes and compatibility. A catalog can be ordered on-line at <https://home.honeywell-online.com/newTMcatalog>. Product data sheets are available on Honeywell's web site at <http://content.honeywell.com/sensing/sensotec/catpages.asp>.